

## PRODUCT MANUAL



*Rechargeable Lithium-Ion Battery*  
*UE-48Li3600WH - Product Manual*

This manual introduces **UE-48Li3600WH** from Upower Ecoline. Please read this manual before you to install the battery and follow the instruction carefully during the installation process. Any confusion, please contact Upower immediately for advice and clarification.

## Table of Contents

<b>1. SAFETY PRECAUTIONS</b>	<b>3</b>
1.1 Before Connecting	4
1.2 In Using	4
<b>2. INTRODUCTION</b>	<b>5</b>
2.1 Features	5
2.2 Specifications	6
2.3 Equipment Interface Instruction	8
UE-48Li3600WH Product Front Interface	8
Definition of RJ45 Port Pin	9
Definition of RJ11 Port Pin	10
LED Indicators Instructions	11
<b>3. SAFE HANDLING OF LITHIUM BATTERIES GUIDE</b>	<b>12</b>
3.1 Schematic Diagram of Solution	12
3.2 Explanation of Symbol	12
3.3 Tools	13
3.4 Safety Gear	13
<b>4. INSTALLATION</b>	<b>14</b>
4.1 Package Items	14
Unpacking and check the Packing List	14
4.2 Installation Location	15
Installation	15
A. Put battery modules into cabinet and connect the cables	15
B. Power On	17
C. Installation with bracket	18
D. Multiple Battery Groups CAN/RS485 Communication Cable Connection	22
<b>5. TROUBLE SHOOTING STEPS</b>	<b>24</b>
5.1 Problem determination based on	24
5.2 Preliminary determination steps	24
5.3 The battery cannot be charged or discharged	24
<b>6. EMERGENCY SITUATIONS</b>	<b>25</b>

## 1. Safety Precautions



### Reminding

- 1) It is very important and necessary to read the user manual carefully (in the accessories) before installing or using battery. Failure to do so or to follow any of the instructions or warnings in this document can result in electrical shock, serious injury, or death, or can damage battery, potentially rendering it inoperable.
- 2) If the battery is stored for long time, it is required to charge them every six months, and the SOC should be no less than 90%.
- 3) Battery needs to be recharged within 12 hours, after fully discharged.
- 4) Do not expose cable outside.
- 5) All the battery terminals must be disconnected for maintenance.
- 6) Please contact the supplier within 24 hours if there is something abnormal.
- 7) Do not use cleaning solvents to clean battery.
- 8) Do not expose battery to flammable or harsh chemicals or vapors.
- 9) Do not paint any part of battery, include any internal or external components.
- 10) Do not connect battery with PV solar wiring directly.
- 11) The warranty claims are excluded for direct or indirect damage due to items above.
- 12) Any foreign object is prohibited to insert into any part of battery.



**Li-ion**



## Warning

### 1.1 Before Connecting

- 1) After unpacking, please check product and packing list first, if product is damaged or lack of parts, please contact with the local retailer.
- 2) Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode.
- 3) Wiring must be correct, do not mistake the positive and negative cables, and ensure no short circuit with the external device.
- 4) It is prohibited to connect the battery and AC power directly.
- 5) The embedded BMS in the battery is designed for 48VDC, please DO NOT connect battery in series.
- 6) Battery system must be well grounded and the resistance must be less than 1Ω;
- 7) Please ensured the electrical parameters of battery system are compatible to related equipment.
- 8) Keep the battery away from water and fire.

### 1.2 In Using

- 1) If the battery system needs to be moved or repaired, the power must be cut off and the battery is completely shutdown.
- 2) It is prohibited to connect the battery with different type of battery.
- 3) It is prohibited to put the batteries working with faulty or incompatible inverter.
- 4) It is prohibited to disassemble the battery (QC tab removed or damaged).
- 5) In case of fire, only dry powder fire extinguisher can be used, liquid fire extinguishers are prohibited.
- 6) Please do not open, repair or disassemble the battery except staffs from Upower or authorized by Upower. We do not undertake any consequences or related responsibility which because of violation of safety operation or violating of design, production and equipment safety standards.

## 2. Introduction

**UE-48Li3600WH** lithium iron phosphate battery is one of new energy storage products developed and produced by Upower, it can be used to support reliable power for various types of equipments and systems. **UE-48Li3600WH** is especially suitable for application scene of high power, limited installation space, restricted load-bearing and long cycle life.


**UE-48Li3600WH** has built-in BMS battery management system, which can manage and monitor cells information including voltage, current and temperature. What's more, BMS can balance cells charging and discharging to extend cycle life.

Multiple batteries can connected in parallel to expand capacity and power in parallel for larger capacity and longer power supporting duration requirements.

### 2.1 Features

- The whole module is non-toxic, non-polluting and environmentally friendly.
- Cathode material is made from  $\text{LiFePO}_4$  with safety performance and long cycle life.
- Battery management system (BMS) has protection functions including over-discharge, over-charge, over-current and high/low temperature.
- The system can automatically manage charge and discharge state and balance current and voltage of each cell.
- Flexible configuration, multiple battery modules can be in parallel for expanding capacity and power.
- Adopted self-cooling mode rapidly reduced system entire noise. The module has less self-discharge, up to 6 months without charging it on shelf, no memory effect, excellent performance of shallow charge and discharge.
- Working temperature range is from  $-10^{\circ}\text{C}$  to  $50^{\circ}\text{C}$ , (Charging  $0\sim 50^{\circ}\text{C}$ ; discharging  $-10\sim 50^{\circ}\text{C}$ ) with excellent discharge performance and cycle life.
- Small size and light weight, standard of 19-inch embedded designed module is comfortable for installation and maintenance.

## 2.2 Specifications




Basic Parameters	UE-48Li3600WH
Nominal Voltage (V)	48
Nominal Capacity (Wh)	3552
Usable Capacity (Wh)	3200
Dimension (mm)	442*420*132
Weight (Kg)	31
Discharge Voltage (V)	44.5 ~ 53.5
Charge Voltage (V)	52.5 ~ 53.5
Recommend Charge/Discharge Current (A)	37
Max. Charge/Discharge Current (A)	74
Peak Charge/Discharge Current (A)	100A@15sec
Communication	RS485, CAN
Configuration (max. in 1 battery group)	8pcs
Working Temperature	0°C~50°C Charge -10°C~50°C Discharge
Shelf Temperature	-20°C~60°C
Protective class	I
Cooling type	Natural Cooling
IP rating of enclosure	IP20
Humidity	0 ~ 85%
Certification	TÜV / CE / UN38.3
Design life	10+ Years (25°C/77°F)
Cycle Life	>4,500 25°C
Reference to standards	IEC62619, IEC62040, IEC62477-1, UL1642, IEC61000-6-2, IEC61000-3

## 2.3 Equipment Interface Instruction

This section details the front and back panel of the interface functions.

### UE-48Li3600WH Product Front Interface



#### Power Switch

Power Switch: to turn ON/OFF the whole battery BMS standby, no power output.

#### ON/OFF

ON/OFF light: green LED lighting to show the Power Switch is ON, and the BMS has electricity (No power output).

#### RUN

RUN light: green LED flashing to show the battery running status.

#### Alarm

Alarm light: red LED flashing to show the battery has alarm, and lighting to show the battery is under protection.

#### SOC

SOC light: 6 green LEDs to show the battery's current capacity.

#### Start

Start Button: press more than 0.5s to start the battery module, Power output ready.

#### ADD Switch

ADD Switch: 4 ADD switches, Dip1 to definite different baud rate ("0" is 115200, "1" is 9600). "0" and "1", refer to picture right. "0XXX" setup the baud rate 115200, and "1XXX" setup the baud rate 9600. The settings will be active only after restart the battery.



The slave battery's address will be assigned automatically. 1 master battery can supervise 7 slave batteries (maximum 8 batteries in each battery group). Multiple battery group should setup the master batteries' ADD switch. (Refer to Chapter 4 / D)



Dip2	Dip3	Dip4	Group Address Number
0	0	0	0th: Single battery group's master battery should setup as this.
1	0	0	1st: 1st battery group's master battery should setup as this.
0	1	0	2nd: 2nd battery group's master battery should setup as this.
1	1	0	3rd: 3rd battery group's master battery should setup as this.
0	0	1	4th: 4th battery group's master battery should setup as this.
1	0	1	5th: 5th battery group's master battery should setup as this.
0	1	1	6th: 6th battery group's master battery should setup as this.
1	1	1	7th: 7th battery group's master battery should setup as this.

## Console

Console Communication Terminal: (RJ11 port) follow RS232 protocol (Baud Rate: 1200), for manufacturer or professional engineer to debug or service.

## CAN

CAN Communication Terminal: (RJ45 port) follow CAN protocol (Baud Rate: 500K), for output batteries information.

## RS485


R485 Communication Terminal: (RJ45 port) follow RS485 protocol (Baud Rate: 9600 or 115200), for output batteries information.

## Link Port 0, 1

Link Port 0, 1 Communication Terminal: (RJ45 port) follow RS485 protocol, for communication between multiple parallel batteries.

## Definition of RJ45 Port Pin

No.	RS485 Pin	CAN Pin
1	RS485 B	--
2	RS485 A	GND
3	--	--
4	--	CANH
5	--	CANL
6	GND	--
7	RS485A (recommend)	--
8	RS485B (recommend)	--




RJ45 Port




RJ45 Plug

## Definition of RJ45 Port Pin

No.	RS232 Pin
1	GND
2	TXD
3	RXD
4	GND



RJ11 Port




RJ11 Plug

## Power Terminals

Power cable terminals: there are two pair of terminals with same function, one connect to equipment, the other one paralleling to other battery module for capacity expanding.

For each single module, each terminal can achieve charging and discharging function.

For power cables uses water-proofed connectors. It must keep pressing this Lock Button during pulling out the power plug.



## Dry Contact Terminal

Dry Contact Terminal: provided 1 way input and 3 ways output dry contact signal.

## LED Status Indicators

- RUN Lamp (No.6 Figure 2-1): green, long lighting when charging and flash when discharging.
- ALM Lamp (No.7 Figure 2-1 7): red, flashes when alarm and long bright if equipment failure or protected.
- Battery capacity indicator (No.8 Figure 2-1): 6 green lamps, each light represent 16.6% capacity.

## LED Indicators Instructions

Condition	RUN	ALR	1	2	3	4	5	6						
Power off	-	-	-	-	-	-	-	-						
Power on	●	●	●	●	●	●	●	●						
Idle/Normal	■	-	-	-	-	-	-	-						
Charge	●	-	Show soc; highest LED flash on: 0.5s; off 0.5s											
Discharge	■	Show soc												
Alarm	ALR: ■; Other LEDs are same as above													
System error/Protect	-	●	-	-	-	-	-	-						
● / ●	ON													
■	Flash, on: 0.3s; off: 3.7s													
■ / ■	Flash, on: 0.5s; off: 1.5s													

BMS function:

Protection and Alarm	Management and Monitor
Charge/Discharge End	Cells Balance
Charge Over Voltage	Intelligent Charge Model
Charge/Discharge Over Current	Charge/Discharge Current Limit
High/Low Temperature (cell/BMS)	Capacity Retention Calculate
Short Circuit	Administrator Monitor
Power Cable Reverse	Operation Record



### 3.3 Tools

The following tools are required to install the battery pack.



Wire cutter



Crimping Modular Plier



Screw Driver

#### NOTE

Use properly insulated tools to prevent accidental electric shock or short circuits.

If insulated tools are not available, cover the entire exposed metal surfaces of the available tools, except their tips, with electrical tape. multiple parallel batteries.

### 3.4 Safety Gear


It is recommended to wear the following safety gear when dealing with the battery pack.



Insulated gloves



Safety goggles



Safety shoes


## 4. Installation

### 4.1 Package Items


Unpacking and check the Packing List

#### 1) For battery module package:

Two power cables and one communication cable for each battery package:



Grounding cable:



Grounding cables use 10AWG yellow-green cables.


UE-48Li3600WH modules' grounding is based on metal directly touch between the module's surface and rack's surface. So it needn't grounding cables at all. If uses normal rack, it can remove the paint at the corresponding place.

Or install a grounding cable to the grounding point of the modules.



#### 2) For battery system connects to inverter:

Two long power cables (current capacity 120A) and one communication cable for each energy storage system:



#### NOTE

These three long cables are **NOT** in battery package, they are in another **extra small cable box**.  
If there is anything missed please contact dealer.

## 4.2 Installation Location

Make sure that the installation location meets the following conditions:

- The area is completely water proof.
- The floor is flat and level.
- There are no flammable or explosive materials.
- The ambient temperature is within the range from 0°C to 50°C.
- The temperature and humidity is maintained at a constant level.
- There is minimal dust and dirt in the area.
- The distance from heat source is more than 2 meters
- The distance from air outlet of inverter is more than 0.5 meters.
- Do not cover or wrap the battery case or cabinet.
- Do not place at a children or pet touchable area.
- The installation area shall avoid of direct sunlight.
- There is no mandatory ventilation requirements for battery module, but please avoid of installation in confined area. The aeration shall avoid of high salinity, humidity or temperature.


### CAUTION

If the ambient temperature is outside the operating range, the battery pack stops operating to protect itself. The optimal temperature range for the battery pack to operate is 0°C to 50°C. Frequent exposure to harsh temperatures may deteriorate the performance and life of the battery pack.

## Installation

A. Put battery modules into cabinet and connect the cables:





- ① Put the battery into the cabinet.
- ② Drive the 4 pcs screws.
- ③ Connect the cables between battery modules.
- ④ Connect the cables to inverter.




## B. Power On


Double check all the power cable and communication cable.

(1) Switch power on


Switch on all the battery modules:



(2) The one with empty **Link Port 0** is the **Master Battery Module**, others are slaves (1 master battery configure with maximum 7 slave batteries):



(2) Press the **red button** of master battery to power on, all the battery LED light will be on one by one from the master battery:



If all the battery LED lights on, and then off, which means the battery system is good and working.

### C. Installation with bracket







1. Dismantle the 2 tabs on the battery.



2. Set the battery into 2 pcs **Bracket** from front and back.





Aim at the 4 pare of Location Pin and Location Hole, stack the batteries together.  
And hasp the 4 agraffes together.

Maximum 4 batteries can be athwart stacked:



One or two batteries can be sidelong stacked:




Cables connection and batteries system start are same as cabinet installation



## NOTE

- To avoid current pulse of the inverter add on the battery bank. Shall start inverter first or switch on breaker between battery and inverter after all connected batteries turned on.
- Between battery bank and inverter should install breaker to protect system safety.
- All the installation and operation must follow local electric standard.


## D. Multiple Battery Groups CAN/RS485 Communication Cable Connection





## Multiple Battery Groups CAN Communication Cable Connection

**Each Communication HUB connects maximum 5 battery piles.**



Each battery pile can configure maximum 8pcs UE-48LI2400WH or UE-48LI3600WH.

## 5. Trouble Shooting Steps

### 5.1 Problem determination based on:

- 1) Whether the battery can be turned on or not;
- 2) If battery is turned on, check the red light is off, flashing or lighting;
- 3) If the red light is off, check whether the battery can be charged/discharged or not.

### 5.2 Preliminary determination steps:

- 1) Battery cannot turn on, switch on the lights are all no lighting or flashing.  
If the battery external switch is ON, the RUN light is flashing, and the external power supply voltage is 48V or more, the battery still unable to turn on, please contact distributor.
- 2) *The battery can be turned on, but red light is lighting, and cannot charge or discharge. If the red light is lighting, that means system is abnormal, please check values as following:*
  - a) Temperature: Above 50°C or under -10°C, the battery could not work.  
Solution: to move battery to the normal operating temperature range between -10°C and 50°C.
  - b) Current: If current is greater than 100A, battery protection will turn on.  
Solution: Check whether current is too large or not, if it is, to change the settings on power supply side.
  - c) High Voltage: If charging voltage above 54V, battery protection will turn on.  
Solution: Check whether voltage is too high or not, if it is, to change the settings on power supply side.
  - d) Low Voltage: When the battery discharges to 44.5V or less, battery protection will turn on.  
Solution: Charge the battery for some time, the red light turn off.

Excluding the four points above, if the faulty is still cannot be located, turn off power switch of the battery and repair.

### 5.3 The battery cannot be charged or discharged

- 1) Cannot be charged:  
Disconnect the power cables, measure voltage on power side, if the voltage is 53~54V, restart the battery, connect the power cable and try again, if still not work, turn off battery and contact distributor.
- 2) Unable to discharge:  
Disconnect the power cables and measure voltage on battery side, if it is under 44.5V, please charge the battery; if voltage is above 48V and still cannot discharge, turn off battery and contact distributor.



## 6. Emergency Situations

### 1) Leaking Batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

Inhalation: Evacuate the contaminated area, and seek medical attention.

Contact with eyes: Rinse eyes with flowing water for 15 minutes, and seek medical attention.

Contact with skin: Wash the affected area thoroughly with soap and water, and seek medical attention.

Ingestion: Induce vomiting, and seek medical attention.

### 2) Fire

NO WATER! Only dry powder fire extinguisher can be used; if possible, move the battery pack to a safe area before it catches fire.

### 3) Wet Batteries

If the battery pack is wet or submerged in water, do not let people access it, and then contact Upower or an authorized dealer for technical support.

### 4) Damaged Batteries

Damaged batteries are dangerous and must be handled with the utmost care. They are not fit for use and may pose a danger to people or property. If the battery pack seems to be damaged, pack it in its original container, and then return it to Upower or an authorized dealer.

#### NOTE

Damaged batteries may leak electrolyte or produce flammable gas.

In case a damaged battery needs recycling, it shall follow the local recycling regulation (ie.

Regulation (EC) N° 1013/2006 among European Union) to process, and using the best available techniques to achieve a relevant recycling efficiency.

Any further questions, please contact Upower: [info@masterbattery.es](mailto:info@masterbattery.es)

#### IMPORTANT NOTICE

The recommended charge/discharge capacity of these batteries is 0.5C (25 or 37 Amp depending on the model), allowing a capacity of 1C (50 or 75 Amp depending on the model), and a maximum charge/discharge capacity of 90/100 Amp in (depending on the model), for a maximum of 15 seconds, using them above the indicated values will immediately void the warranty. Please pay special attention to the dimensioning of the installation. In the case of connecting the batteries with an equipment that does not have, or is not configured in lithium mode, the maximum charge/discharge will not be higher than 10A, being out of any guarantee if this value is exceeded.

#### WARRANTY

To obtain the warranty, the following requirements must be met: the battery must not be discharged with a current greater than 25A/37A depending on the model.

The sizing of the battery modules must be in accordance with the power of the inverter, improper operation voids the warranty, as the 25A/37A supplied by each module is exceeded.